# **ROOM TEMP. & HUMIDITY TRANSMITTER**

(GRTHO-1420S)



## **Application**

"GRTHO" Room Temperature & Humidity Transmitter is intended control transmitter by sensing relative humidity and temperature of room ventilation and air-handling units.

Also can be used interface detect transmitter with sensing value display or auto control system of building.

### **Equipment Combinations**

- Pulp, Food warehouse, greenhouse, computer room, R&D room, Hospital etc.
- Use as measuring Transmitter: In case of Optimistic function system

#### **Technical Data**

SUPPLY VOLTAGE : DC 15~30V
OUTPUT SIGNAL : 4-20mA

SENSING RANGE : Temp. / -20~+70℃, Humi. / 0~100%RH

SENSING ELEMENT : Integrated Circuit

SELF GENERATING CURRENT : below 2mA (0.02 OHM / 0.05Deg.)

● ACCURACY : at 25°C Within ±3%, at 20~90%RH, Within ±3%RH

• WIRING : 4 Wire

• SENSING TIME : Within 30sec

• AMBIENT TEMPERATURE :

1) On Operation: -30~+70°C

• AMBIENT HUMIDITY :

1) On Operation: 5 ~ 100%RH

2) On Transportation & Storage: below 95%RH

PROTECTION CLASS : IP54(EN 60529)

• WEIGHT : 0.17Kg

#### **Notes**


Engineering:

1) In case of control: Preferably install on the wall of house or building, and keep away from direct light.

## **Mounting & Installation**

- Installation height: Preferably install in the middle of house, building or heating area, and to be installed at least 1.5 meter above from the floor.
- Prohibited Location: Window, door, Ventilating hole, upper place of heat source, and veranda or beneath the eaves of roof.
- To prevent any detecting error from convection of warm, air, cable wire tube of transmitter should be shielded and must not be painted.

## **Wiring Diagram**



### **Dimension**

